

# Installation instructions for blaugelb Trio**therm** pre-wall installation system How to achieve perfect insulation.





The relevant standards and guidelines are covered by the following system tests\*:

Component test (attachment)	7	ift guideline MO-02/1	V
Component test (sealing)	7	ift guideline MO-01/1	V
<b>ETB dynamic</b> (connection of a fall-arresting system to the structure, pendulum impact)	5	requirement from the ETB guideline "Components providing fall arrest protection	on"
<b>ETB static</b> (connection of a fall-arresting system to the structure, compression test)	7	requirement from the ETB guideline "Components providing fall arrest protection	on"
Concentrated load tests (static rated values for resistance, rated vertical/horizontal values)	5	ift guideline MO-02/1	V
Burglary resistance for RC 2 and RC 3	5	pursuant to DIN EN 1627 to EN 1630 requirements	
Sound insulation	<u> </u>	DIN EN ISO 10140-1 and EN ISO 717-1	V
Passive house certified	<b>-</b>	Passive House Institute, window fitting system	
Fire protection		GAS MPA Braunschweig	V

<sup>\*</sup>Tests are available to download from www.blaugelb.de or on enquiry

#### Notes:

Keep a record of how to process a specimen of the blaugelb Trio $\it therm+$  system.

Use the installation instructions to train the personnel performing the work. Our staff would be happy to assist you in a specimen installation.

 $\label{thm:condition} \mbox{Keep a record of the work performed using the appropriate installation report.}$ 

RC 2 and RC 3 according to DIN 1628-30: Installation instructions see  ${\bf Appendix\ IV}$ 

ETB guideline "Components providing fall arrest protection" installation instructions see Appendix V

How to achieve perfect insulation.

# Please read these installation instructions carefully before commencing installation!

Please note that you should fit a "specimen" of the blaugelb Trio**therm+** profiles on the structure before starting installation work. This is so that you can verify whether the blaugelb Hybrid Polymer Power Fix establishes a connection between the profile and the anchor base. The anchor base must be firm and stable. The client, architect, site manager or structural engineer is responsible for ensuring that the anchor base is firm and stable.

The anchor base must be free of loose parts and bituminous or greasy separating layers (e.g. bituminous seals, oil released on concrete structures, tiles, foils, etc.)

If there is a separating layer on the anchor base, this can be removed using a diamond cup wheel (e.g. Forum diamond cup wheel 125 mm, item no. 6602027196).



#### Time:

At least 24 hours before actually starting to install the blaugelb Trio**therm+** system

### Specimen size:

At least 200 mm of the blaugelb Triotherm+ profile to be used

### Procedure:

Apply two beads of sealant (blaugelb Hybrid Polymers Power Fix) to the specimen of blaugelb Trio**therm+** profile and position it on the anchor base. Warning: Do not screw it to the anchor base.

#### **Evaluation:**

After at least 24 hours (at least 48 hours if under  $+5^{\circ}$ C), load the test specimen with approx. 800 N (81.5 kg).



#### **Documentation:**

This must be done using the report provided. The report must be filed in the relevant construction records.

**Safety note:** While creating and loading the test specimen, please observe all accident prevention and essential health and safety measures. It is imperative to avoid injuries to the person carrying out the work or to bystanders.

### Note on dovetail joints:

To seal before joining, apply a little blaugelb Hybrid Polymer Power Fix in a U shape.






In the area of the dovetail joint a screw connection (to the profile above) must be made at a distance of 100 mm from the joint, regardless of the usual fixing spacings.



### >>> Direction of cutting >>>



**Note on screwing blaugelb Triotherm+ profiles:** Set the torque of the cordless screwdriver to the required level. Note that you should start screwing the blaugelb Frame screw Fix FK-T30 onto the blaugelb Triotherm+ profile slowly.

How to achieve perfect insulation.

### Preparing for installation:

Inspecting the anchor base



The surfaces of the anchor base must be checked for flatness and vertical and horizontal alignment. Make allowance for centre line tolerances and masonry tolerances.

1. Check the supporting anchor base for loose parts, bituminous and/or separating coatings. If there are any separating layers on the anchor base, these must be removed, e.g. using a diamond cup wheel.



2. Bind/remove normal construction dust on the anchor base (at the desired position for the profile) with the aid of a damp brush.



### Fabricating the profiles:

1a. Required length of the lower and upper profile:

Complete element width

- + planned connecting joint dimension (2x 10 mm)
- + cross-section of the side profile (2x 85 mm)


### = final dimension of the horizontal profiles

1b. Required length of the side profiles:

Complete element height

+ planned connecting joint dimension (1x 10 mm)

= final dimension of the vertical profiles





2. Cut off the "socket" on the outer blaugelb Triotherm+ profile.



3. Join the blaugelb Trio**therm+** profiles together by dovetailing. Always start with the offcut from the piece previously cut to size. The offcut should be no shorter than 250 mm. To join together, apply a little blaugelb Hybrid Polymer Power Fix in a U shape to create the seal.



Transfer the length dimension to the assembled profiles.



4. Saw the blaugelb Triotherm+ profiles to the correct length



Recommended tool: Mitre saw with coarse longitudinal-cut blade (e.g. blaugelb HW Saw Blade 250x3.2/2.2x30 mm Z24 W item no. 0399564).

### Applying the sealant:

- 1. Open the tubular bag containing the blaugelb Hybrid Polymer Power Fix and insert it into a sealant gun for tubular bags.
- 2. Use the supplied 6 mm triangular nozzle to apply the sealant. There is a marking on the nozzle to facilitate precise application.



3. Apply the blaugelb Hybrid Polymers Power Fix on the side facing the wall. The two beads must be applied at a sufficient distance from the edge. We recommend applying the adhesive promptly onto all profiles for an opening in the structure.

#### Recommended tool:

Cordless gun for 600 ml tubular bag (item no. 9066040) for uniform application of the sealant requiring less physical effort.

How to achieve perfect insulation.



Note: Under normal conditions (23°C and 50% relative humidity) the sealant will start to form a skin after approx. 5 minutes.

### Fitting the profiles on the anchor base:

1. The specific position of the horizontal base should be marked on the anchor base according to the planned position of the element (central or axial installation). The centre markings on the profile and anchor base indicate the precise position for vertical alignment. For horizontal alignment, use the breast edge of the element opening as a guide or a height previously clearly marked using the reference marker. We recommend always aligning using the reference marker.





2. Press the prepared blaugelb Trio**therm+** profile firmly against the anchor base, making sure it remains in the marked position. The profile can be pressed on firmly using a hammer with rubber attachment.



The applied blaugelb Hybrid Polymer Power Fix works immediately as an ancillary fixative. Its high initial adhesion means that the profile adheres immediately at the intended position. Slight adjustments to its alignment will be possible for up to about 20 minutes after applying to the anchor base.

3. Bring the blaugelb Trio**therm+** profile into the desired horizontal position and align it using a long spirit level or a laser.





4. Seal the butt joint between the horizontal and vertical profiles on one side using blaugelb Hybrid Polymer Power Fix. Bring the prepared side blaugelb Triotherm+ profiles into the correct position and press them firmly onto the anchor base.





5. Fit the upper blaugelb Trio**therm+** profile. Seal the butt joints of the side profiles using blaugelb Hybrid Polymer Power Fix.



6. Position the blaugelb Trio**therm+** profile and press it firmly onto the anchor base and the side profiles.



### **Drilling the holes:**

1. Mark the attachment points on the blaugelb Triotherm+ profiles as specified. For optimal load transfer, the defined corner distance for the lower blaugelb Triotherm+ profile as seen from outside is 150 mm (65 mm from the inside edges). Depending on the element width, further fixing screws may need to be screwed in so that the maximum spacing between the screws is not exceeded.





Always work on the basis of 200 mm from the inside corners, except in the case of the lower profile.



How to achieve perfect insulation.

2. Drill the attachment points on the masonry. To do so, drill directly through the blaugelb Trio**therm+** profiles at the marked points as far as the specified screw-in depth.



### Screwing the profiles on:

1. Attach the blaugelb Trio**therm+** profiles using the blaugelb Frame screw Fix FK-T30 of the appropriate length for the anchor base and necessary screw-in depth.



### Fitting the window element:

The sealing method shown here using multifunctional tape and blaugelb Hybrid Polymer Power Fix is provided solely by way of illustration. The sealing method can be freely selected in accordance with the guidelines for proper window fitting.

 Select the blaugelb Multifunctional Tape TrioSDL600 according to the planned joint width and contact area between the blaugelb Triotherm+ system and the element profile.

Please note that it is not the construction depth of the element that is critical for the choice of multifunctional tape, but the actual contact area. If the multifunctional tape expands because it is too wide, its functions will be impaired.

2. Fix the blaugelb Multifunctional Tape Trio**SDL600** on the inside of the blaugelb Trio**therm+** profiles on three sides (top and both sides) in accordance with the guidelines for proper window fitting.



Once the upper tape has been fixed in position, use the blaugelb 40x60x10 mm Spacer Block (item no. 0416311) to mark the space that the upper tape needs in order to expand.



The side multifunctional tapes can then be fitted.







3. Apply a trace of blaugelb Hybrid Polymer Power Fix to the lower blaugelb Triotherm+ profile as a sealant.



4. The window frame is then fitted into the frame aperture using the blaugelb Sill Connection Profile EPS.



### Fixing the window element:

1. Align the window element vertically and horizontally and fix it in the correct position using window fixing pads.



2. Note the fixing specifications / fixing spacings (**Appendix III**) when screwing the window frame into the blaugelb Trio**therm+**. It is essential that you observe these. Use **only** the blaugelb Frame screws FK/ZK-T30 7.5 mm to fix the window elements directly in the blaugelb Trio**therm+** profile. Do not pre-drill the blaugelb Trio**therm+** profiles.

Recommendations for installation:

- plastic window: blaugelb Frame screw Fix FK-T30 7.5 mm
- wooden window: blaugelb Frame screw Fix ZK-T30 7.5 mm
- wood/aluminium window: blaugelb Frame screw Fix ZK-T30 7.5 mm
- aluminium window: blaugelb Frame screw Fix ZK-T30 7.5 mm



Determine the length of screw required:


Window frame width (view from inside)

- + planned joint width
- + screw-in depth in blaugelb Triotherm+ profile (min. 60 mm)

= minimum screw length

### Appendix I:

Edge distances for the blaugelb Triotherm+ pre-wall installation system



- 5 | blaugelb Multifunctional Tape Trio**SDL600**
- (10) | blaugelb Hybrid Polymer Power Fix
- 14 blaugelb Frame screw Fix ZK-T30 7.5 x L
- (15) blaugelb Frame screw Fix FK-T30 7.5 x L
- (22) | blaugelb Triotherm+ profile 70x85 mm
- (51) | Supporting wall structure



# Appendix II:

# Rated resistances of the blaugelb Trio**therm+** pre-wall installation system

F<sub>4</sub> Rd vertical load (rated value of the resistance in the window plane)

	la la coma della	F, <sub>Rd</sub>	Wall material						
F1-4	blaugelb	FY <sub>H, Rd</sub>	quality						
Figure	Triotherm+	in N	Concrete	Sand-lime brick	Hollow brick	Hollow brick	Porous concrete	Porous concre	
	profiles		C25	Comp. strength class 12	Comp. strength class 8	Comp. strength class 12	PP4	PP2	
			in N	in N	in N	in N	in N	in N	
1	70 x 85 mm without support	Values in N	2.560	1.571	1.571	1.571	1.571	1.571	
	1 screw	Values in kg	260	160	160	160	160	160	
2	70 x 85 mm without support	Values in N	2.730	1.840	1.600	1.600	х	×	
	2 screws	Values in kg	278	187	163	163	х	х	
3	70 x 85 mm with support	Values in N	4.940	4.260			X	×	
	3 screws	Values in kg	503	434	X	X	X	X	
4	100 x 85 mm without support	Values in N	1.270	914	х	х	x	x	
	1 screw	Values in kg	130	93	х	X	x	×	
5	100 x 85 mm without support	Values in N	1.730	1.250	X	×	×	×	
	2 screws	Values in kg	176	127	Х	х	х	х	
6	100 x 85 mm with support	Values in N	4.250	3.060	2.754	2.754	2.754	2.754	
	150x100x85 mm 3 screws	Values in kg	433	312	280	280	280	280	
7	120 x 85 mm without support	Values in N	1.270	914	914	914	914	x	
	1 screw	Values in kg	130	93	93	93	93	x	
8	120 x 85 mm without support 2 screws	Values in N Values in kg	1.710	1.275	1.275	1.275	1.275	1.275	
		Values in N	174	130	130	130	130	130	
9	120 x 85 mm with support 150x120x85 mm		4.150	2.990	2.754	2.754	2.754	2.754	
	3 screws	Values in kg	423	304	280	280	280	280	
10	140 x 85 mm without support	Values in N	1.710	1.231	х	x	х	x	
	2 screws	Values in kg	174	125	X	Х	X	х	
11	140 x 85 mm with support 150x140x85 mm	Values in N	4.600	3.312	2.754	2.754	2.754	2.754	
	3 screws	Values in kg	468	337	280	280	280	280	
12	160 x 85 mm with support	Values in N	2.400	2.650	1.805	1.805	1.805	1.805	
	150x160x85 mm 3 screws	Values in kg	244	270	184	184	184	184	
13	180 x 85 mm	Values in N	3.360	2.648	1.805	1.805	1.805	1.805	
	with support 150x180x85 mm 4 screws	Values in kg	242	270	104	404	404	404	
4.4	200 x 85 mm	Values in N	342	270	184	184	184	184	
14	with support 150x200x85 mm		3.360	2.648	1.805	1.805	1.805	1.805	
	4 screws	Values in kg	342	270	184	184	184	184	
15	230 x 85 mm with support 200x230x85 mm	Values in N	3.826	2.755	1.710	1.710	1.710	1.710	
	4 screws	Values in kg	390	280	174	174	174	174	
	1 - 301 0443	<u> </u>	330	200	. , , ¬	1 177	1/7	17-9	

How to achieve perfect insulation.

# Appendix II:

# Screw-in depths of the blaugelb Triotherm+ pre-wall installation system

### Screw-in depths in base

blaugelb	C	Base material						
Triotherm+	Screw information	Quality						
profiles		Concrete C25	Sand-lime brick Compressive strength class 12	Hollow brick Compressive strength class 8	Porous concrete PP4 / PP2	Wood ≥ 450 kg/m		
70 x 85 mm	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
	Screw length in mm	112	132	212	212	132		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø 6 mm		
100 x 85 mm	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
100 X 85 mm	Screw length in mm	132*	152*	252	252	152*		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø 6 mm		
120 x 85 mm	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
	Screw length in mm	182	182	252*	252*	182		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø6mm		
140 x 85 mm	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
	Screw length in mm	182	212	300	300	212		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø 6 mm		
160 × 95	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
160 x 85 mm	Screw length in mm	212	212*	300	300	212*		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø 6 mm		
	!				•			
180 x 85 mm	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
	Screw length in mm	212*	252	300**	300**	252		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø6mm		
	Screw-in depth in mm	I			1			
200 x 85 mm	Screw length in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
	Pre-drilling in base	252 Ø 6 mm	252* Ø 6 mm	350 Ø 5 mm	350 no	252* Ø 6 mm		
	-				1			
230 x 85 mm	Screw-in depth in mm	min. 40	min. 60	min. 142	min. 142	min. 60		
	Screw length in mm	300	300	350**	350**	300		
	Pre-drilling in base	Ø 6 mm	Ø 6 mm	Ø 5 mm	no	Ø 6 mm		

<sup>\*:</sup> Countersink screws for securing profile 10 mm in blaugelb Triotherm+ profile

 $<sup>\</sup>ensuremath{^{*:}}$  Countersink screws for securing profile 20 mm in blaugelb Triotherm+ profile




### Appendix III:

### Legend for the following installation drawings



### **Optional support**

Depending on wall structure and forces exerted, see Appendix II: Rated resistances and screw-in depths



### B blaugelb Frame screw Fix FK-T30 7.5 x L / ZK-T30 7.5 x L

Fixing the window frame into the blaugelb Trio**therm+** system L = screw-in depth in the blaugelb Trio**therm+** system min. 60 mm, for RC 2 / RC 3 min. 70 mm

# P blaugelb Protect

Fixing the window frame into the anchor base using the blaugelb Frame screw Fix FK-T30 7.5 x L

L = screw length of the blaugelb Frame screw Fix FK-T30 7.5 x L and length of the adjusting screw, see blaugelb Protect installation instructions

# R blaugelb Frame screw Fix FK-T30 7.5 x L

Fixing the Triotherm+ profile in the anchor base

L = screw length depending on wall structure and forces exerted, see Appendix II: Rated resistances and screw-in depths

# blaugelb Plinth Thermal Insulation Profile EPS blaugelb Plinth Thermal Insulation Profile IHP/EPS blaugelb Plinth Thermal Insulation Profile PVC/EPS

### blaugelb Assembly bracket

Fixing the blaugelb Plinth Thermal Insulation Profile into the anchor base using the blaugelb Frame screw Fix FK-T30 7.5 x L

L = screw length depending on the anchor base; dimensioning depending on the height of the blaugelb Plinth Thermal Insulation Profile

# | blaugelb Sill Connection Profile

Placed directly on the blaugelb Triotherm+ profile with blaugelb Hybrid Polymer Power Fix


### Y Structure heights

(floor structure, roller shutter structure)

### **Joint dimension**


According to the elongation (  $\Delta T$ ) of the frame material

Attachment points of the blaugelb Triotherm+ pre-wall installation system on the anchor base






Attachment points of the element on the blaugelb Trio**therm+** pre-wall installation system




Attachment points of the blaugelb Triotherm+ pre-wall installation system – combined diagram






# Appendix IV:

Attachment points of the element on the blaugelb Triotherm+ pre-wall installation system – RC 2



# Appendix IV:


Attachment points of the element on the blaugelb Triotherm+ pre-wall installation system – RC 3





# Appendix V:

Attachment points of the element on the blaugelb Triotherm+ pre-wall installation system - ETB



# Expert. Honest. Reliable.

For more information, please visit www.meesenburg.com

Our partner



Fentro Technologies Inc. 150 Grant St Morden MB R6M 1Y4 Canada info@fentro.com www.fentro.com